

# ReadmeFirst

## Tuner4TRONIC

2021-12-14

**Important: Please extract the zip file to your computer before running the installation file. Running the installation file from inside the zip file will lead to installation problems!**

**To avoid any path length problems during installation it is recommended to extract the zip to a short location like C:\temp.**

This package contains the following components:

- Install Tuner4TRONIC (T4T Install.exe) --> This is the installer for the Tuner4TRONIC Software Suite (T4T-P and T4T-S).
- ISSetupPrerequisites (folder)

This folder is needed by "T4T Install.exe" in order to install the FEIG programming interfaces SW drivers.

**This folder must be copied into the same folder as T4T Install.exe before executing the installer!**

In case you already use FEIG readers, please ensure that the FEIG reader have the following firmware installed:

- v1.5.0 for CPR30
- v2.4.0 for PRH101-USB.

If the FEIG readers have an older firmware version, please update their firmware before using them with T4T. Please check FEIG's website for latest firmware downloads.

- Tuner4TRONIC Release Notes.pdf

This document describes the changes compared to last version and known issues to be taken into account when using the T4T.

- DALI magic FW Update Tool (folder)

T4T requires a DALI Magic with a firmware version 2.54 or newer.

Using this tool, the user can update the DALI Magic firmware to version 2.54 on Windows 10 computers.

This folder contains a Windows tool that guides the user through the FW upgrade process.

- MagicUpdater 2\_54.exe (executable)

- OT Programmer USB driver (folder)

When using the OT Programmer, no additional drivers need to be installed. However, on some Windows installations the drivers might not be available and need to be installed manually. If OT Programmer is not recognized by the computer, please disconnect the OT Programmer, execute the drivers installer and re-connect the OT Programmer.

The drivers included here are the original drivers as provided by FTDI for the USB hardware interface which is used in the OT Programmer.

- User Manuals (folder)

Contains the latest versions of the user manuals for T4T-Production, T4T-S (SimpleCurrent Tool), T4T-CMD and T4T-DLL.

- readme first.txt --> this file